

iPod/iPhone動作確認一覧表

ファームウェア 20.0.0以降

●オーディオ・ビデオ再生可、○オーディオ再生可(ビデオ再生不可)、×再生不可

Table with columns for device type (iPod nano, iPod touch, iPhone), model, and compatibility status (●, ○, ×) for various audio and video formats across different hardware versions.

【機能制限に関する注記】

- List of technical notes regarding device functions, such as video playback issues, audio quality, and system updates.

【注意事項】

- List of important user notices regarding device usage, including warnings about overheating, liquid damage, and software updates.

動作が不安定な場合や正常に動作しない場合は、下記いずれかの方法をお試しください。
特定のファイルが再生できない等の場合、iPod/iPhone本体では問題なく再生できることを事前に確認してください。

iPod nano 7世代、iPod touch 第5/6/7世代、iPhone 5/5S/5C、6/6Plus、6S/6SPlus、SE、7/7Plus、8/8Plus、X、XS、XS Max、XR、11、11Pro、11Pro Max、NEW SE、11、11Pro
については、ナビと接続する際にiPod、iPhone付属のUSBケーブルを使用する必要があります。

<USB/HDMI入力端子のご使用について>
オーディオ再生する場合、iPod、iPhone付属のUSBケーブルを使用する必要があります。

<iPod/iPhoneにポッドキャスト・オーディオブックの楽曲が保存されている場合の注意事項(OS8.0以降)>
下記状況代表例を記載が発生する場合があります。

iPod/iPhoneの掲載適用範囲「販売開始～Apple社のサポート終了まで」とさせていただきます。(2018年分より)