

こちらの表をご覧ください。

R3 (2021) 年11月現在

エンジン型式	タイミングベルト 【10万km交換】	タイミングチェーン 【無交換】	タイミングギヤ 【無交換】
A 2 5 A - F K S		○	
A 2 5 A - F X S		○	
T 2 4 A - F T S		○	
1 A - U	○		
2 A - U	○		
3 A - U	○		
2 A - L U	○		
3 A - L U	○		
4 A - E L U	○		
4 A - G E U	○		
4 A - G E	○		
4 A - F	○		
5 A - F	○		
5 A - F E	○		
4 A - F E	○		
5 A - F E	○		
7 A - F E	○		
1 A Z - F S E		○	
2 A Z - F S E		○	
2 A Z - F E		○	
2 A Z - F X E		○	
1 A R - F E		○	
2 A R - F X E		○	
2 A R - F S E		○	
2 A R - F E		○	
8 A R - F T S		○	
B 4 8			○
B 5 8			○
B			○
2 B			○
3 B			○
4 B			○
1 1 B			○
1 3 B			○
1 3 B - T			○
1 4 B			○
1 4 B - T			○
1 5 B - F			○
1 5 B - F T			○
1 5 B - F T E			○
1 B Z - F P E			○
1 C	○		
1 C - L	○		
1 C - T L	○		
2 C - L	○		
2 C - T	○		
2 C	○		
3 C - E	○		
3 C - T (E)	○		
2 D			○
2 E系	○		
3 E系	○		
2 E - L U	○		
2 E - E L U	○		
2 E - L J	○		
4 E - F	○		
4 E - F E	○		
5 E - F E	○		
5 E - F H E	○		
E J - D E	○		
E J - V E	○		
2 F			○
3 F			○

エンジン型式	タイミングベルト 【10万km交換】	タイミングチェーン 【無交換】	タイミングギヤ 【無交換】
FA20		○	
FA24		○	
F33A-FTV		○	
1FZ-FE		○	
G16E-GTS		○	
1G-EU	○		
1G-GEU	○		
1G-GTEU	○		
1G-GZEU	○		
1G-EJ	○		
1G-FE	○		
1G-GPE	○		
1GD-FTV		○	
2GD-FTV		○	
1GZ-FE		○	
1GR-FE		○	
2GR-FE		○	
2GR-FSE		○	
2GR-FXE		○	
2GR-FXS		○	
2GR-FKS		○	
3GR-FSE		○	
4GR-FSE		○	
8GR-FXS		○	
2H			○
12H-T	○		
1HZ	○		
1HD-T	○		
1HD-FE	○		
1HD-FT	○		
1HD-FTE	○		
HC-EJ	○		
J05C			○
1JZ-GE	○		
1JZ-GTE	○		
2JZ-GE	○		
2JZ-GTE	○		
1JZ-FSE	○		
2JZ-FSE	○		
1KR-FE		○	
1KR-VET		○	
2K		○	
3K		○	
3K-U		○	
4K-U		○	
4K-EU		○	
4K-J		○	
5K-J		○	
5K		○	
7K		○	
7K-E		○	
1KD-FTV	○		
2KD-FTV	○		
1KZ-TE	○		
K3-VE		○	
K3-VE2		○	
KF(ターボ有無に関わらず)		○	
L	○		
2L	○		
3L	○		
5L	○		
2L-T	○		
2L-TE	○		
2L-THE	○		
1LR-GUE		○	

エンジン型式	タイミングベルト 【10万km交換】	タイミングチェーン 【無交換】	タイミングギヤ 【無交換】
M15A-FKS		○	
M15A-FXE		○	
M20A-FKS		○	
M20A-FXS		○	
M-U		○	
M-EU		○	
4M-EU		○	
5M-EU		○	
M-TEU		○	
5M-GEU	○		
6M-GEU	○		
7M-GTEU	○		
1MZ-FE	○		
2MZ-FE	○		
3MZ-FE	○		
1N	○		
1N-T	○		
1ND-TV		○	
N04C			○
1NR-FE		○	
1NR-FKE		○	
2NR-FKE		○	
2NR-VE		○	
8NR-FTS		○	
1NZ-FE		○	
2NZ-FE		○	
1NZ-FXE		○	
1NZ-FXP		○	
1NZ-FNE		○	
1PZ	○		
R			○
3R			○
3R-B			○
12R			○
5R		○	
5R-U		○	
16R-U		○	
18R-U		○	
18R-GEU		○	
19R		○	
21R-U		○	
22R		○	
RZ		○	
1RZ-E		○	
2RZ-E		○	
3RZ-FE		○	
3RZ-FP		○	
3RZ-FPE		○	
1S-U	○		
1S-LU	○		
2S-ELU	○		
1S-iLUS	○		
1S-ELU	○		
3S-GELU	○		
3S-FE	○		
3S-GE	○		
3S-GTE	○		
3S-FSE	○		
4S-FE	○		
5S-FE	○		
S05C			○
S05D			○
1SZ-FE		○	
2SZ-FE		○	
3SZ-VE		○	
T		○	
T2		○	
2T		○	

エンジン型式	タイミングベルト 【10万km交換】	タイミングチェーン 【無交換】	タイミングギヤ 【無交換】
T-U		○	
2T-U		○	
2T-GEU		○	
3T-GTEU		○	
3T-EU		○	
12T		○	
12T-U		○	
13T-U		○	
1TR-FE		○	
1TR-FPE		○	
2TR-FE		○	
2TZ-FE		○	
2TZ-FZE		○	
1UR-FE		○	
1UR-FSE		○	
2UR-GSE		○	
2UR-FSE		○	
3UR-FE		○	
1UZ-FE	○		
2UZ-FE	○		
3UZ-FE	○		
V35A-FTS		○	
4V-U		○	
4V-EU		○	
5V-EU		○	
1VZ-FE	○		
3VZ-E	○		
3VZ-FE	○		
4VZ-FE	○		
5VZ-FE	○		
WA-VEX		○	
WA-VE		○	
1W			○
2Y		○	
3Y		○	
3Y-E		○	
3Y-J		○	
3Y-U		○	
3Y-EU		○	
2Y-PU		○	
3Y-P		○	
3Y-PU		○	
3Y-PE		○	
1ZZ-FE		○	
2ZZ-GE		○	
2ZR-FE		○	
3ZR-FE		○	
2ZR-FAE		○	
3ZR-FAE		○	
2ZR-FXE		○	